



FMBGFK21 VAG FITTING INSTRUCTIONS



Please thoroughly read through and familiarise yourself with these instructions in their entirety, prior to beginning any part of the installation process of any component. Failure to install these products correctly may void your warranty. To avoid risking possible skin burns or other injuries please ensure the vehicle and engine has cooled down sufficiently.

TOOLS NEEDED:

- Side cutters & pliers/sharp blade
1. Open the car bonnet and locate the vacuum port on the inlet manifold
 2. Release the OE vacuum pipe by pressing the clip and pulling the pipe away at the same time, this will allow the vacuum pipe to come away.

3. Push the Forge vacuum T over the vacuum port on the inlet manifold as far as it will go, secure it with the E-clip provided and reconnect the OEM vacuum hose (removed in Step 2.) to the other side of the Forge vacuum T.



4. Push one end of the supplied silicone vacuum hose onto the Forge vacuum T and secure it with a cable tie. Run the vacuum hose to the part you are adding and cut to length with scissors or a sharp knife. Use cable ties provided to route it away from any moving parts.

Your installation is now complete, take the vehicle for a test drive and enjoy your new Forge Motorsport product.

Check out WWW.FORGEMOTORSPORT.CO.UK and WWW.FORGEMOTORSPORT.COM

For a full range of performance products for your vehicle.

If you have any questions or concerns about this product or anything else, please feel free to contact your local or preferred Forge Motorsport Dealer/Installer or you may contact us directly.

Forge Motorsport UK (+44)1452 380999
Forge Motorsport USA (407)-447-5363
Forge Motorsport ASIA +886-4-22516887

info@forgemotorsport.co.uk
sales@forgemotorsport.com
sales@forgemotorsport.asia



Forge Motorsport



@forgemotorsport



@forgemotorsport



Forge Motorsport